



# Racorería Rosca ORFS





**EMPALME  
MACHO**

ORFS

Rosca Rosca 1	Rosca Rosca 2
9/16	9/16
11/16	11/16
13/16	13/16
1"	1"
1" 3/16	1" 3/16
1" 7/16	1" 7/16



**EMPALME  
MACHO**

ORFS-GAS (BSP)

Rosca ORFS	Rosca GAS
9/16	1/4
11/16	1/4
11/16	3/8
13/16	3/8
13/16	1/2
1"	1/2
1" 3/16	3/4
1" 7/16	1"



**EMPALME  
MACHO**

ORFS-SAE (UNF)

Rosca ORFS	Rosca SAE
9/16	7/16
11/16	9/16
13/16	3/4
1"	3/4
1"	7/8
1" 3/16	1" 1/16
1" 7/16	1" 5/16



### CODO 90°

MACHO ORIENTABLE

ORFS-GAS (BSP)

Rosca ORFS	Rosca GAS
9/16	1/4
11/16	1/4
11/16	3/8
13/16	3/8
13/16	1/2
1" 3/16	3/4
1" 7/16	1"



### CODO 90°

MACHO ORIENTABLE

ORFS-SAE (UNF)

Rosca ORFS	Rosca SAE
9/16	7/16
11/16	9/16
13/16	9/16
13/16	3/4
1"	3/4
1"	7/8
1" 3/16	1" 1/16
1" 7/16	1" 1/16
1" 7/16	1" 5/16



### TAPÓN MACHO

**Rosca**

9/16  
11/16  
13/16  
1"  
1" 3/16  
1" 7/16



**TAPÓN  
HEMBRA**

**Rosca**

- 9/16
- 11/16
- 13/16
- 1"
- 1" 3/16
- 1" 7/16



**CODO 90°**

**MACHO FIJO  
TUERCA LOCA**

<b>Rosca Macho</b>	<b>Rosca Hembra</b>
9/16	9/16
11/16	11/16
13/16	13/16
1"	1"
1" 3/16	1" 3/16
1" 7/16	1" 7/16







**suhimar**  
suministros  
hidráulicos

Pere III el Cerimoniós, 39  
Telf./ Fax. 937 996 159  
08303 - Mataró  
Barcelona  
[mataro@suhimar.com](mailto:mataro@suhimar.com)